



INSTRUCTIONS FOR TOP TEC 15 x 15 FRAME CANOPY

- STEP 1 Assemble frame as in diagram.
- A. Assemble perimeter first. NOTE: WHEN ASSEMBLING FOURTH SIDE, MALE-FEMALE CONNECTION SHOULD BE THE FINAL CONNECTION.
 - B. Connect roof rafters.
 - C. Connect Clusters. NOTE: CONNECT CORNER RAFTERS TO CLUSTER FIRST (SHORTER TUBE ON CLUSTER); THEN INTERMEDIATES.
- STEP 2 Lay top over frame.
- STEP 3 Insert legs into the brackets.
- STEP 4 Attach tent to frame by means of side release buckles.
- STEP 5 Raise tent to desired height.
- NOTE: To disassemble reverse steps.